



**OFFSET DRAG** SCALE: 1/8" = 1'-0" 23

**ROOF TRANSFER** SCALE: 1/8" = 1'-0" 19

**GABLE END BRACE** SCALE: 1/8" = 1'-0" 14

**TRUSS** AT GIRDER TRUSS SCALE: 1/8" = 1'-0" 8

**ROOF FRAMING AT GIRDER TRUSS** SCALE: 1/8" = 1'-0" 3

**ROOF TRUSS AT FLOOR TRUSS AT BEAM** SCALE: 1/8" = 1'-0" 21

**RAFTER/TRUSS EXTERIOR WALL** SCALE: 1/8" = 1'-0" 13

**RAFTER** AT BEAM SCALE: 1/8" = 1'-0" 11

**TRUSS/WALL** SHAR TRANSFER SCALE: 1/8" = 1'-0" 6

**ROOF TRUSS** EXTERIOR WALL SCALE: 1/8" = 1'-0" 1

**ROOF TRUSS** PER PLAN SCALE: 1/8" = 1'-0" 16

**OFFSET GABLE END ROOF TRUSS** SCALE: 1/8" = 1'-0" 16

**RAFTER** AT BEAM SCALE: 1/8" = 1'-0" 11

**TRUSS/WALL** SHAR TRANSFER SCALE: 1/8" = 1'-0" 6

**ROOF TRUSS** EXTERIOR WALL SCALE: 1/8" = 1'-0" 1

**ROOF TRUSS** PER PLAN SCALE: 1/8" = 1'-0" 16

**OFFSET GABLE END ROOF TRUSS** SCALE: 1/8" = 1'-0" 16

**RAFTER** AT BEAM SCALE: 1/8" = 1'-0" 11

**TRUSS/WALL** SHAR TRANSFER SCALE: 1/8" = 1'-0" 6

**ROOF TRUSS** EXTERIOR WALL SCALE: 1/8" = 1'-0" 1